



**When replacing the lower printed circuit board N7196,
label wires when disconnecting.**

**Be sure to re-attach field wiring to the standoffs
on the circuit board as shown below.**

