



# N1225 or N1387 Alternator with N3135 or N3225 Regulator

## OEM Wiring Connections - Dual or Single Voltage

### Installation Instructions

#### DUAL VOLTAGE (28 V/14 V) applications (see other side for single voltage):

1. Connect as shown on this page in Figures 1a-c.




Figure 1a - Regulator Dual Voltage Wiring Connections




Figure 1b - Positive Terminal Connections




Figure 1c - Ground Terminal Connections

**SINGLE VOLTAGE (28 V) applications** (see other side for dual voltage):

2. Connect as shown on this page in Figures 2a-c.




Figure 2a – Regulator **Single Voltage** Wiring Connections




Figure 2b – Positive Terminal Connections

Figure 2c – Ground Terminal Connections

If you have questions about your alternator or any of these instructions, or if you need to locate a Factory Authorized Service Dealer, please contact us at:

C. E. Niehoff & Co. • 2021 Lee Street • Evanston, IL 60202 USA

TEL: 800.643.4633 USA and Canada • TEL: 847.866.6030 outside USA and Canada • FAX: 847.492.1242

E-mail us at [service@CENiehoff.com](mailto:service@CENiehoff.com)